Additional Installation Notes for Iron Fence:

1. You have 9 panels for the 68ft run adding up to a little over 72ft with posts. One panel will need trimmed.

2. You have 10 panels for the 76ft run adding up to a little over 80ft with posts. One panel will need trimmed.

3. The gate with posts and hardware will be 13ft wide

4. You will need to provide the 3/8in anchor bolts for the flange posts. Each post requires 4.

5. I don't love hanging the big 6ft leafs on a flange post. I would recommend drilling the top brackets for the panels on each side of the gate and putting another screw in them to tie the gate to 2 posts.